

Starting Options

4.3" IPS Colour Touch Display

Touch_IT AC4


arcus-eds

Display Format and System Settings


When the device is started up (AUX or USB) the landscape or portrait mode is adapted according to the installation.



Portrait



Landscape




Page Design in the ETS Software


Download ETS Application Touch_IT V2

Select page design 2x4 or 2+6.


2 x 4




2 + 6



Select a colour scheme of icons. Choose between DARK and BRIGHT icons in the ETS.



bright icons



dark icons

e8 / Subject to change