

Übersicht / Aperçu / Panoramica

Weisse Tasterkappe: -00 / bouton blanc : -00

Schwarze Tasterkappe: -01 / bouton noir: -01

Symbole | Symboles | Simboli

Beispiel

Maru-P.12-T-13-00 weiss / blanc

Maru-P.12-T-13-01 schwarz / noir

Artikelnummer / Numéro d'article/ Numero di articolo

Maru-P.12-B-3-0x		Maru-P.12-B-4-0x		Maru-P.12-B-6-0x	
Maru-P.12-B-7-0x					
Maru-P.12-D-1-0x		Maru-P.12-D-4-0x		Maru-P.12-D-5-0x	
Maru-P.12-D-6-0x		Maru-P.12-D-14-0x		Maru-P.12-D-15-0x	
Maru-P.12-D-16-0x		Maru-P.12-D-17-0x		Maru-P.12-D-18-0x	
Maru-P.12-D-19-0x		Maru-P.12-D-20-0x		Maru-P.12-D-26-0x	
Maru-P.12-D-27-0x		Maru-P.12-D-30-0x		Maru-P.12-D-32-0x	
Maru-P.12-D-39-0x					
Maru-P.12-L-1-0x		Maru-P.12-L-3-0x		Maru-P.12-L-7-0x	
Maru-P.12-L-8-0x		Maru-P.12-L-9-0x		Maru-P.12-L-10-0x	
Maru-P.12-L-14-0x		Maru-P.12-L-16-0x		Maru-P.12-L-17-0x	
Maru-P.12-L-18-0x		Maru-P.12-L-19-0x		Maru-P.12-L-20-0x	
Maru-P.12-L-21-0x		Maru-P.12-L-22-0x		Maru-P.12-L-23-0x	
Maru-P.12-S-0-0x		Maru-P.12-S-4-0x		Maru-P.12-S-5-0x	
Maru-P.12-S-10-0x		Maru-P.12-S-11-0x		Maru-P.12-S-13-0x	
Maru-P.12-S-17-0x		Maru-P.12-S-18-0x		Maru-P.12-S-19-0x	

[illegible]